LED High Bay Sensor

MODEL OD-MC628VRC



Instruction Manual



WARNING

WARNING — THE INSTALLATION MUST BE CARRIED OUT BY A QUALIFIED ELECTRICIAN.

- 1. LED High Bay Sensors are not suitable for using in wet locations
- 2. Please keep the LED High Bay Sensor away from any corrosive substance, and please use dry cloth when you clean it
- 3. LED High Bay can only be installed by a qualified electrician
- 4. Before installation or maintenance, please disconnect the power to prevent electric shock



Application Notice

- 1. The sensor should be installed by a professional electrician. Please turn off the power before installing, wiring, changing the setting of the DIP switch
- 2. The sensor which installed in the plastic and glass lampshade will reduce the sensitivity. For every 3mm increase in thickness, the sensitivity will be reduced by 20%
- 3. The dimming performance could be different from different 1-10V drivers
- 4. The light sensitivity threshold is in a sunny environment, no shadow and ambient light diffuse reflection. Lux level detected by sensor could be different in different environment, weather, climate, time-of-day and season
- 5. The parameters of the sensor may need to be reconfigured in different installation environments. Please refer to the following instructions or contact the manufacturer
- 6. This sensor is for indoor use only. It will affect the waterproof effect for outdoor use. Wind, rain, and moving objects around will cause false triggering
- 7. The distance between any inductive sensors should be greater than 3m
- 8. Do not place the sensor close to high-density objects such as metal, glass, concrete walls, etc, false triggering could happen. When the sensor is installed in a metal lamp, metal reflective surface, or a narrow enclosed environment, the microwave will be reflected repeatedly and cause false triggering. Please reduce the sensitivity or contact the manufacturer for technical support
- 9. Please ensure that there are no moving signals around the sensor, such as fan, DC motor, sewer pipe, air outlet, etc., the sensor may generate false trigger
- 10. You are advised to test 5 samples before mass application of sensor in a new lighting project
- 11. Due to continuous improvement, the contents of this instruction could be changed without prior notice

CAUTION

PLEASE READ INSTRUCTION BEFORE COMMENCING INSTALLATION AND RETAIN FOR FUTURE REFERENCES. Electrical products can cause death or injury, or damage to property.

If in any doubt about the installation or use of this product, consult a competent electrician.

INSTALLATION GUIDE

Initialization

1/ On/off function /3step dimming function: After power on, the sensor automatically turns on light at 100% brightness. After 10sec, it turns off the light. During the initialization, the sensor is not able to detect movement.

2/ 2-step dimming function: After power on, the sensor automatically turns on light at 100% brightness. After 10sec, it dims the light to a low light level (set by stand-by dim level). During the initialization, the sensor is not able to detect movement.


Factory Setting

Detection area: 100%, Hold time: 5s. Stand-by Period: 0s. Stand-by dim level: 10%, Daylight Sensor: Disable


Instruction Manual

FUNCTIONS


ON/OFF Function (stand-by period be set to "0"s)



1. With sufficient ambient light, the light will not be switched on even if with motion signal




2. With insufficient ambient light, the sensor switches on the light when motion is detected



3. After elapse of hold time, the sensor switches off the light when no motion is detected

2-step Dimming Function (stand-by period be set to "+∞")



1. If there is no motion detected, the light will be remained at a low light level all the time




2. When motion is detected, the sensor will switch on the light to 100% brightness



3. After elapse of hold time, the sensor switches dims the light at the present low light level if no motion is detected


3-step Dimming Function (stand-by period be set to "10s/1min/3min/5min/10min/30min")




1. With sufficient ambient light, the light will not be switched on even if with motion signal



2. With insufficient ambient light, the sensor switches on the light when motion is detected




3. After elapse of hold time, the sensor switches dims the light at a low light level if no new motion is detected




4. After elapse of standby period, the sensor switches off the light if no motion is detected in the detection zone

Daylight Priority (stand-by period set to +∞)



1. Lamp turns on at low light level 10% in the night



2. Motion detected, lamp automatically lights up to 100%



3. After hold time, the lamp gradually dims to a low light level 10% if no movement detected




4. Lamp turns off after dawn



Instruction Manual


WIRING



*The sensor is designed for connect one load only.

Connect more than one loads may damage the sensor.

FUNCTION DIAGRAM





Instruction Manual

REMOTE CONTROL

REMOTE-MH10

