

REPLACEMENT PARTS

Contact your dealer or the factory for questions concerning prices and policies on replacement parts. Normally all parts can be ordered through your Authorized dealer / distributor.

FOR WARRANTY REPLACEMENT PARTS, A PHOTOCOPY OF THE ORIGINAL INVOICE WILL BE REQUIRED TO HONOUR THE CLAIM.

When ordering replacement parts always give the following information:

- Model and serial number of appliance
- Installation date of appliance
- Part number
- Description of part
- Finish

FOR FURTHER INFORMATION, CONTACT YOUR AUTHORIZED DEALER.

⚠ WARNING

FAILURE TO POSITION THE PARTS
IN ACCORDANCE WITH THIS
MANUAL OR FAILURE TO USE ONLY
PARTS SPECIFICALLY APPROVED
WITH THIS APPLIANCE MAY
RESULT IN PROPERTY DAMAGE OR
PERSONAL INJURY.

COMPONENTS							
REF.	LEDFP-50	LEDFP-50W	LEDFP-60	LEDFP-60W	LEDFP-72	LEDFP-72W	DESCRIPTION
1	B300-0226	B300-0227	B300-0228	B300-0229	B300-0230	B300-0231	FRONT GLASS
2	B475-1192	B475-1192	B475-1193	B475-1193	B475-1195	B475-1195	ACRYLIC PLASTIC PANEL
3	B405-0033	B405-0033	B405-0033	B405-0033	B405-0034	B405-0034	LED LIGHT
4	B497-0014	B497-0014	B497-0014	B497-0014	B497-0015	B497-0015	PLASTIC STRIP
5	B080-1616	B080-1616	B080-1616	B080-1616	B080-1616	B080-1616	WALL MOUNTING BRACKET
6	B080-1618	B080-1618	B080-1618	B080-1618	B080-1619	B080-1619	Log set
7	B527-0009	B527-0009	B527-0009	B527-0009	B527-0010	B527-0010	REFLECTOR SPINDLE
8	B435-0077	B435-0077	B435-0077	B435-0077	B435-0077	B435-0077	SYNCHRONOUS MOTOR
9	B010-3728	B010-3728	B010-3728	B010-3728	B010-3728	B010-3728	BLOWER AND HEATER ASSEMBLY
10	B190-0095	B190-0095	B190-0095	B190-0095	B190-0095	B190-0095	REMOTE CONTROL
11	B190-0096	B190-0096	B190-0096	B190-0096	B190-0101	B190-0101	CIRCUIT BOARD
12	B497-0019	B497-0019	B497-0019	B497-0019	B497-0020	B497-0020	CRYSTAL
13	B370-0050	B370-0050	B370-0050	B370-0050	B370-0051	B370-0051	HARDWARE KIT
14	B475-1184	B475-1184	B475-1184	B475-1184	B475-1184	B475-1184	CONTROL PANEL (WITH REMOTE RECEIVER)
15	B690-0021	B690-0021	B690-0021	B690-0021	B690-0021	B690-0021	THERMOSTAT

NOTE: Care must be taken when removing and disposing of any broken glass or damaged components. Be sure to vacuum up any broken glass from inside the appliance before operation.

