

LED WALL PACKS

M-WP25-3CCT+W

WARNING

WARNING - THE INSTALLATION MUST BE CARRIED OUT BY A QUALIFIED ELECTRICIAN.

- LED Wall packs are suitbale for using in wet, dry and damp locations
- · Please keep the LED Wall packs away from any corrosive substance, and please use dry cloth when you clean it
- LED Wall packs can be installed by a qualified electrician
- · Before installation or maintenance, please disconnect the power to prevent electric shock


APPLICATION NOTICE


- DO NOT exceed using the standard working voltage
- BE SURE the power supply is turned off before installation
- SWITCH OFF power of main supply or the connection lead respectively before doing any works
- Please note waterproof, dustproof, electricity prevention and shockproof for the external power wires
- BE SURE the connection between the wires is in good condition when isntalling the lamps, beware of leakage

CAUTION

PLEASE READ INSTRUCTION BEFORE COMMENCING INSTALLATION AND RETAIN FOR FUTURE REFERENCES. Electrical products can cause death or injury, or damage to property. If in any doubt about the installation or use of this product, consult a competent electrician.

INSTALLATION GUIDE





INSTRUCTIONS:

STEP 1: Disassemble the fixing screws of the lamp mounting plate with a screwdriver and remove the mounting plate.

STEP 2: After knocking out the mounting holes with a hammer (at least 2 mounting holes and they should be in a symmetrical position), press the bracket on the wall with your hand and mark with the pen at the mounting screw position.

STEP 3: Use the electric drill to punch the hole at the mark position Ø8mm, depth 40mm; and use a hammer to drive the plastic expansion tube into the hole.

STEP 4: Fix the bracket with a screwdriver, and fix the fixture installation wire rope on the mounting plate, connect the cable as shown and do a good waterproof treatment.

STEP 5: Put the lamp back on the mounting plate and secure the screws to complete the installation.











LED WALL PACKS

M-WP25-3CCT+W

ADJUSTING WATTAGE AND CCT




00

Ō

3

F



INSTRUCTIONS:

STEP 1: Unscrew the screws of the fixture with a screwdriver and remove the fixture.

STEP 2: Turn the fixture over to reveal the wattage and CCT adjustment device(adjust to the required wattage and CCT as the figure).

STEP 3: Put and lock the fixture back on the mounting plate to finish the installation.



