



### WARNING

**WARNING — THE INSTALLATION MUST BE CARRIED OUT BY A QUALIFIED ELECTRICIAN.**

1. Disconnect and lock-out all power sources during installation as severe injury or death can result from electrical shock due to contact with high voltage conductors
2. Never rely on status indicating devices only to determine if power is present in a conductor
3. Ensure all installations are in compliance with applicable electrical codes and that the installation is completed by qualified installers familiar with the standards and proper safety procedures for high voltage installation

### CAUTION

**PLEASE READ INSTRUCTION BEFORE COMMENCING INSTALLATION AND RETAIN FOR FUTURE REFERENCES.**

**Electrical products can cause death or injury, or damage to property.**

**If in any doubt about the installation or use of this product, consult a competent electrician.**

### INSTALLATION GUIDE

**1.**

**2.**

**4.**

**3.**

**5.**

**6.**

**7.**

**8.**

**9.**

1. Take out sensor and sensor bracket.
2. Install the sensor and fix it with M4\*6 screws.
3. Install the sensor head and fix it with M3\*4 screws.
4. Press the buckle on both sides and remove the lamp housing.
5. Take off linear strip cover.
6. Install the sensor bracket and fix it with M3\*6 screws.
7. The locking effect is as shown in the fig.
7. Wiring according to the wiring diagram and checking the wiring is correct.
8. After checking, put back the lamp housing.
9. The installed effect is shown in fig. 9.